

Ignite

Why is my controller screen flashing in the top right corner



This means that there is a firmware update available for automatic download. Best advice is to keep your controller up to date with the latest firmware releases.

To carry out this upgrade, press the right arrow to scroll through to the settings screen on the controller

Press up arrow to highlight system settings, now press right key to display.



Now press the up arrow until the next screen appears.



Press PWR button to accept update and screen will change to



Once downloaded, controller will re boot and install new updated firmware release.

Congratulations, your now up to date